

ME3000 TROUBLESHOOT "Check EESUM error"



The units microprocessor flash memory was corrupted by a voltage surge.

This will disable the unit as a safety precaution.

To rectify:-

Push and hold all of the following four keys simultaneously for 5+ seconds

"1 + 8 + B + cancel" until the units display reboots to ME3000 v1.7 software.

Then push and hold "stop" and "cancel" buttons for 5+ seconds until display shows:-

"Push button A to program". Then push "A" key....

Enter the original programming parameters to match the original set flowmeter and application.

(If unsure provide the original serial number of the unit, or send back for overhaul/service)

"Check EESUM error"

factory key:

1+8+B+cancel (press simultaneous)

"FAULT-ZERO 420"

cancel+stop (press simultaneous)



ManuFlo®™

Flow Measurement & Control Products